

Introducing the DigiFi™ Music Server Quick Start

TV Interface



Contents

- 01 Introduction**
- 02 The TV Interface**
 - Music Library — Albums**
 - Music Library — Tracks**
 - Now Playing — Tracklist**
- 05 Ripping a CD**
- 06 Playing an Album**
- 08 Selecting a Track**
- 09 Queuing**
- 09 Saving a Tracklist**

01

Introducing the DigiFi™ Music Server


The DigiFi™ Music Server stores your CD collection and plays it through your Hi-Fi.

The music on the Server is controlled using the infra-red control - you can see exactly what's happening on the DigiFi™ interface displayed on a connected TV.

The DigiFi™ Interface makes it easy and intuitive to select and play albums and tracks, and to create, edit and listen to playlists.

This Quick Start guide gives instructions for basic operation.

Please refer to the full User Guide for more detailed instructions. It also covers advanced functions, installation, and configuration.




02

The TV Interface

The DigiFi™ TV Interface is based on a colour-coded menu system and integrates well with the remote control.

It's easy to use and intuitive to learn. If you have digital multi-channel TV you will be very familiar with what we are about to describe.

Although the remote control is fairly sophisticated, we have designed the interface so that you can even do all the popular functions using just the 5 keys < > < > (plus SELECT) in a cross at the top of the infra-red remote.



03

The TV Interface

There are 3 screens you're likely to use the most:

Music Library — Albums

Where you'll find your music collection displayed.

Music Library — Tracks

Lets you see all the tracks on your album or playlist.

Now Playing — Tracklist


Shows you the tracks in the Now Playing Tracklist.



Music Library — Albums



Music Library — Tracks



Now Playing — Current Track

04


The TV Interface

For normal listening, it is a simple matter of 'toggling' between the Music Library and Now Playing screens to play albums, and using the Tracks screen to select individual tracks.

At any time selecting one of the colour keys on the screen or remote will take directly to where you need to go.

Volume can be adjusted by pressing + or - on the remote (note - audio quality is better if you leave this at 100% and adjust the overall level on your amplifier).

Use the $\left[\right]$ keys on the remote to access and select the options below the tracklist. These let you, for example, pause the current track, to select the repeat function or play tracks at random.



05

Ripping a CD

Just place a CD in the tray and close.

The DigiFi™ will do the rest, copying the music from your CD on to the server.

After a short time, normally about 5 minutes, the CD will pop out.

Press the green button on the handset to go to Music Library. You'll notice that the album has appeared in the Music Library A-Z screen.

You can now play the album.



06

Playing an album

Most people start by using the A-Z function on the Music Library screen. In fact this is the first screen you see when you switch on your DigiFi™ and it shows the whole list of all artists and their albums.

You can press a letter on the remote to quickly find an artist/album or just use the **[AV]** keys to scroll down the list. You'll see the yellow navigation bar move as you do this.

When you find the album you want (Play Selected will be highlighted by to show this) press SELECT on the remote.

The server will automatically start playing the album and the Now Playing screen will appear. This screen shows the album and artist details, the track length, and the tracks on the tracklist.

You can either add albums (Add Album) or individual tracks (Add Track) to your Playlist.



07

Playing an album

Although most people start by using the A-Z function in the Music Library, there are more screens you will find useful.

The Music Library menu screen gives you some of the more popular options which will be relevant after you have ripped some music into your music library.

This Music Library menu screen is accessed by pressing the green button on the remote when you are in the Now Playing screen.

Scroll through the options in the usual way using the **< >** keys on the remote. Press SELECT to go into any option.



Music Library Menu

08

Selecting a Track

Go to Music Library.

Scroll down and highlight an album.

Use **[X]** on the remote to highlight Select Tracks and press SELECT. The tracklist for the album will be displayed. Highlight a track.


To play the track, press SELECT on the remote. The track will play and the Now Playing screen will appear.

Alternatively, you can select Add. This adds the track to the end of the Now Playing tracklist.

You can change tracks on the Now Playing screen in two ways:

Either press SELECT on the remote when the track you want to listen to is highlighted.

Or select the Next or Prev buttons on screen.



09

Queuing

The Now Playing screen also works as your personal tracklist.

You can keep adding albums or individual tracks to this tracklist.

You can also save this tracklist as a Playlist and give it a name for future use.

Saving a Tracklist

After you have selected your tracks, select the Blue button on the remote to take you to Main Menu.

Highlight Save Now Playing Tracklist option and press SELECT on the remote. Now name your Playlist.

Use **[V]** on the remote to highlight Save and press SELECT. Your playlist is now saved.

You can now find your playlist within Playlists and play it at any time.



Saving a Tracklist (cont)

Choose a name for your Playlist




SELECT to save your Playlist


Finding your Playlist

Press the green button on the remote to take you into the Music Library menu. Scroll down to Playlists and press SELECT. You'll then find your playlist.

SELECT Playlists



Your Playlist, press SELECT to play



Discover an entirely new music collection — Your own

Once you've mastered basic album and track selection, and created and saved tracklists, you can go on to experience all the other features that the DigiFi™ Music Server has to offer.

This includes Creating Playlists, Defining Genres, Advanced Searches, and Random and Repeat functions.

To find out more, please refer to the User Guide

